尺寸：140X105MM

DECLARATION

This manual without any kind of warranty, the position of expression or other implied.If any because of the use of all of the information of the manual, or they use the products mentioned, caused by direct or indirect loss of data, loss of profits, or the cause of termination of the Company, our company and our employees definitely do not assume any responsibility.In addition, the specifications of the products mentioned in this manual for information purposes only, may be modified according to the product specific to prevail in kind, the content will be updated at any time absolutely without prior notice.

Product and company names talked about in this manual are only for identification purposes, these names may be registered trademarks and copyrights of other companies.

USER MANUAL

TIPS

For your safety, while driving please do not watch video or operating this machine. Set the volume to clearly hear outside sound levels while driving. Before you begin, carefully read this manual and other manuals and understand this manual and machine safety tips and warning signs, after reading it, please put it on the readily accessible place for ready reference.

1.First pay attention to traffic safety.

2. If when you encounter difficulties in operating the system, park your car in a safe place before the operation.

3.Please do not let children operate this machine, so as not to cause personal injury or damage to the machine.

4.When using satellite navigation feature, please follow the rules of the road driving.

5.Please do not use this machinery in place to prohibit the use of electronic equipment or open flame is prohibited, such as gas stations, wineries, electromagnetic strong interference region, or it may be dangerous

6.Do not self-service, maintenance, or install the machine. In case of the power is on, do not install or repair the machine. It is very dangerous if the person who did not receive the electronic equipment or vehicle installation training or lack of experienced personnel to install and repair the machine.

7.Do not store or install the machine in direct sunlight place, nor to be placed in the environment of other harmful substances, especially LCD screen, when installing, if the LCD screen just in the air conditioner near the ventilation duct, to ensure that cold do not wind or hot air blowing directly on the machine, otherwise it may damage the machine, even for personal injury.

8.Do not use sharp objects to scratch or paint on the display, do not take a hard object vigorously push on the display, otherwise it will cause damage to the display or the touch screen.

9.In order to ensure the normal operation of the machine and to prevent the occurrence of fire or electric shock, do not expose it in the moist air, also do not to let the liquid spilled on the machine.

SAFETY CAUTION

Please read through the manual before you install this machine. You're suggested to ask the professional car audio engineers to install this machine.

This product fits for 12V car power system(must be connected with the ground wire).Please do not install this product to the car with 24V power system. Or the machine will be damaged.

Please do not change the power fuse by yourself without any guide of the professional people. Use the unsuitable fuse, will lead to the damage of the machine or cause fire alarm.

To avoid violating the traffic rules, the drivers are not allowed to watch programs or operate this machine when driving, in order to avoid unnecessary traffic accident.

For safety and ensure the normal use of this product, please askthe professional people to install this product, and do not disassemble or maintain this product, to avoid the damage of this product and some accidents, details please refer to your local car audio shops.

Please do no put this product in damp environment and water,to avoid the electric shock caused by short circuit,or other unnecessary losses and fire alarm.

Attention: To avoid short circuit, please note to turn off the car and disconnect the connection of cable ACC with B+ before install the machine.

PRODUCT'S RESET

1.At the first time to use this machine or after changing the car battery,you are required to reset the machine.

2. When the functions of this machine are abnormal, you are required to reset the machine.

3. Use a substance which is with cusp, press the RESET button which is in the face plate. In setting system click Initialize Settings, let the machine in its initial state.

Attention: Press RESET button or make system in its initial state which will make the previous time and memory lost.

Menu

Interface Operation 02

Navigation 03

TV/AUX 04

DVD 05

Bluetooth 06

Radio 08

iPod 09

SD/USB 10

System Settings 11

Audio Settings 12

GPS/time setting 13

Language/background setting 14

Frequently Asked Questions 15

Care And Maintenance 16

Interface Operation

Turn on navigation then access to main menu,it has two pages.

photograph1

Tap screen and slide right to next page as photograph 1



photograph2

Tap screen and slide left to last page as photograph 2

NAVIGATION

Set navigation as follow

Icon

1:Put map to GPS slot, clink"Icon"to Navi setting

1:Setting 2:Folder Icon

2:Clink “setting” , then clink “Folder Icon”



Last page

Next page

3:Clink folder , choose AddrBook
Clink next page to choose “Navione.exe”, then return to main menu

6:Navigation start after finish above step

TV/AUX



NO.	Icon	Function
1		Search the TV channel
2		Search channel up
3		Search channel down
4		last TV channel Next TV channel
5		Search the channel
6		Storage the TV channel

1.In AUX mode,when signal input,system will turn to image automatically.

2.Clink top left corner will show ,return to main menu

DVD



NO.	Icon	Function
1		pause/play
2		stop
3		Last Track/Next Track
4		Fast forward
5		Cycleplay
6		Next menu
7		Main menu
8	SUB_T	Choose subtitles DVD mode
9		Stereo
10	GOTO	Show the information of CD/DVD
11		Setting
12		Turn down the volume
13		Turn up the volume
14		Previous menu
15		Link to keypad to choose play list
16		Choose and setup tracks in Mp3 mode

Bluetooth

Enter the mobilephone pair setup



Answer Missed calls Call incoming

Missed call Refresh phonebook



Connect

Delete pairing record

Delete

Return

Call

Phonebook of SIM(GPS) card

Check phonebook of mobilephone

Refresh phone book

Bluetooth



Hang up Key to dial interface

Redial



Changes Bluetooth name and password

Play the music on the mobile phone by bluetooth

Radio



NO.	Icon	Function
1	EQ	Sound mode
2	⏮ ⏭	Search the radio station
3	AMS	Auto search and store radio channels
4	BAND	Band switching
5	LOC/DX	Receiving the strong signal of radio station frequency
6	PTY	Program type/ Station menu
7	FAV	Display station list automatic
8	AF	On-Off of RDS
9	ST	Stereo/Mono this setting will work on FM and bands
10	TA	Search the traffic information channels

Note:

AF/TA work only when device have RDS function

iPod

NO.	Icon	Function
1	MENU	Back to the main menu
2	⏮ ⏭	Last Track/Next Track
3	◀◀ ▶▶	Speed /Fat rewind button
4	⏯	Suspend/Play
5	🔁	Stcohastic Pattern
6	🔀	Recurrence Pattern
7	EQ	Sound mode

SD/USB



NO.	Icon	Function
1	⏮ ⏭	Last Track/Next Track
2	⏹	Stop
3	⏯	Suspend/Play
4	🔁	Stcohastic Pattern
5	🔀	Recurrence Pattern
6	EQ	Sound mode
7	📁	Folder in the SD card
8	🎵	Music in the SD card
9	🎞	Moive in the SD card
10	📷	Picture in the SD card

Note:

SD menu interface is the same as USB menu interface.

System Settings



Time display: System Time Display ON/OFF

Brake: ON—All video will stop playing with reminding words in screen when tick it

System initialization: Restore Factory settings

Radio location: Radio location Settings

TV Video System: PAL N,PAL M,PAL I,PAL B/G,PAL D/K,SECAM L',SECAM L,SECAM D/K, SECAM B/G ,NTSC M/N.

Audio Settings





All Model Audio Settings: Navigation/BT/DVD/TV/iPod/Aux In/Radio

LOUD: Four Speakers sound at the same time

6 Sound Effects: Custom/Standard/Pop/Rock/Classic/Jazz

Tips:

"Front, Back, Left, Right" is used for adjusting each in car louder speakers' volume

GPS/time setting





This picture shows the GPS signal, Click can redetect GPS signal

24HR:Swap 12-hour system to 24- hour system

GPS Sync: system time is synchronous with GPS or not

Language/background setting



Language Settings



System Background settings

Frequently Asked Questions

1.Question: Failure to open the unit
Reason : Haven't installed the bus pod or haven't install the bus pod properly
Solution : configure the bus pod properly

2.Question: Failure to enter the GPS navigation
Reason :Not setting the gps navigation route correctly
Solution : reset the gps navigation route

3.Question: No BT function
Reason : No mobile telephone connection
Solution : Enter the BT setup and check the machine name and code

4.Question: Failure of touch screen
Reason : Touch screen deflected
Solution : recalibrate the touch screen

5.Question: Failure of specific speaker
Reason : Incorrect audio setup
Solution: configure speaker properly

6.Question: Failure of navigation's signal
Reason : Not insert the GPS antenna or not configure the GPS antenna correctly
Solution : Insert the GPS antenna properly

Care and Maintenance

The car entertainment & navigation systems need to be operated carefully, considering its excellent design and technology. The following suggestions will help you to fulfill the obligation of warranty terms and conditions.

1.Keep all the parts, accessories of the car entertainment & navigation systems away from the children.

2.Please keep dry. The rainwater, moisture and other kinds of liquid may contain mineral substance, which will corrode the electronic circuits. The soaking or moisture will ruin the components, cause irreparable damage.

3.Do not use or put the headunits in the dusty or smudgy place, which may damage its detachable elements.

4.Keep the headunits away from the extremely hot place. The high temperature will shorten the acceptable life, damage the battery , deform or melt the plastic parts.

5.Keep the headunits away from the extremely cold place. Otherwise the temperature increment may accumulate moisture inside, which will damage the circuit board.

6.Please do not throw, knock or shock the machine with great force, otherwise it may be ruined.

7.Do not attempt to destructuralize the machine, this will damage it, especially to the non-professionals.

8.Do not use the strong chemicals, detergent or strong abluent to wash the machine.

9.keep away the electromagnetic, radioactive or magnetic equipment when use the machine or store it.

10.When wipe the screen, use the soft and clean cloth, ordinary paper is not recommended.

11.The LCD screen is scraped easily, please use the touch pen when operate. To avoid the damage on the screen, other sharp objects are not recommended.